



Video Door Phone Quick Installation Guide




1 Package Contents



2 Physical specification



Device size	195 x 120 x 34 (mm)
-------------	---------------------

1) Panel



2) Interface description

Open the rear case of the device, there is a row of terminal blocks for connecting the power supply, electric lock control, etc. The connection is as follows:





Serial number	Description
1	Ethernet interface: standard RJ45 interface, 10/100M adaptive, it is recommended to use five or five types of network cable
2	Power interface: 12V/1A input left positive, right grounded
3、5	Two sets of short-circuit input detection interfaces: for connecting switches, infrared probes, door magnets, vibration sensors and other input devices
4、6	Two sets of short-circuit output control interface: used to control electric locks, alarms, etc.
7	Wiegand interface
8、9	Two sets of door magnetic detection
10	Recording output interface: Mix the device and the sound of the far-end call. One is the recording signal line, and the other is the ground line (be sure to ground the line, otherwise there will be noise)
11	External active speaker interface: external active speakers for audio power amplification. One is the audio signal line, and the other is the ground line (be sure to ground the line, otherwise there will be noise)
12	JP1 jumper

JP1 Jumper

There are two modes for power supply of electric-lock as shown in the picture below. (The default is "Passive Mode:").

Passive Mode: When the electric-lock starting current is more than 12V/500mA, need to use the external drive mode, the electric lock interface for short circuit output control.


Active Mode : When the electric-lock starting current is less than 12V/500mA, can use the internal drive mode, the electric lock interface is 12V DC output.



3) Wiring instructions:

NO: Normally Open Contact
 COM: Common Contact
 NC: Normally Close Contact


Driving Mode		Electric-lock Mode		JP1 Jumper	Connections
Active	Passive	No electricity when open	Electricity when open		
✓		✓			<p>12V + - Power Supply 12V/1A</p> <p>S S-O NC COM NO</p> <p>Indoor switch</p> <p>Electric-lock (Normally Open Mode)</p> <p>No electricity when open the door</p>
✓			✓		<p>12V + - Power Supply 12V/1A</p> <p>S S-O NC COM NO</p> <p>Indoor switch</p> <p>Electric-lock (Normally Close Mode)</p> <p>When the power to open the door</p>
	✓	✓			<p>Door Phone Power Input</p> <p>S S-O NC COM NO</p> <p>Power Supply 12V/2A</p> <p>Indoor switch</p> <p>Electric lock (normally open type)</p> <p>No electricity when open the door</p>
	✓		✓		<p>Door Phone Power Input</p> <p>S S-O NC COM NO</p> <p>Power Supply 12V/2A</p> <p>Indoor switch</p> <p>Electric lock (normally closed type)</p> <p>When the power to open the door</p>



3 Installation Diagram

Wall-mounted:

- 1) Use built-in screw tool to remove the surface shell;
- 2) Based installation dimensions, mounting hole in the wall to draw, use an electric drill holes lay;
- 3) The white rubber plugged into the wall and the bottom fixed with screws to the wall;
- 4) After connecting the power cord and network cable, screw the surface shell fixed.




4 Searching Door Phone

There are two methods as shown below to search the device.

Method 1:

Open the iDoorPhone Network Scanner. Press the Refresh button to search the device and find the IP address.

(Download address <http://download.fanvil.com/tool/iDoorPhoneNetworkScanner.exe>)



Method 2:

Long press DSS key for 10 seconds(after power-on for 30 seconds), and when the speaker beeps rapidly, press DSS key again quickly, the beeps stop ,the intercom will report the IP address by itself.


In addition, device provides the device surface DSS key operation to switch IP address acquisition mode:

Long press the DSS key for 10 seconds, to be issued by the speaker Beep, and then press the DSS key three times, the beep stops. Wait 10 seconds, after the success of the system automatically broadcast the current IP address.

5 IP Door Phone Setting


Step 1: Log in the door phone

Input IP address (e.g. http://192.168.1.128) into address bar of PC's web browser.
The default user name and password are both admin.



Step 2: Add the SIP account.

Set SIP server address, port, user name, password and SIP user with assigned SIP account parameters.
Select "Activate", and then click Apply to save this setting.



Step 3: Setting DSS key

Set the DSS key as shown below for a quick start. Click "Apply" to save this setting.


Type: Hot Key

Number 1: The DSS Key will dial to this Number 1.

Number 2: If Number 1 is unavailable, it will be forwarded to Number 2.

Line: Working line

Subtype: Speed dial





Fanvil Technology Co., Ltd

Add: 4F, Block A, Building 1#, GaoXinQi Hi-Tech Park (Phase-II),
67th District, Bao'An, Shenzhen, China P.C:518101

Tel:0755-2640-2199 Fax:0755-2640-2618 Email:sales@fanvil.com